



INSTRUCTIONS

4 DOOR BRONCO SIDE MOLLE PANELS

Thank you for purchasing your 4 Door Bronco Side MOLLE Panels from AAL! We greatly appreciate your trust in our company. We take that purchase and your commitment to us very seriously. If you have any questions along the way, please don't hesitate to give us a call at 385.202.4188.

Step 1 - Lay Out All Components (What's Included)

Components Included:

- (x2) Driver/Passenger Side MOLLE Panels
- (x2) Side Specific Top Panels

Hardware Included:

- (x2) M5 Button Head Bolts
- (x2) M5 Nyloc Nuts



Step 2 - Assemble the Panels

You will need to assemble the top panels to the side panels using the provided hardware. Make sure to insert the bolt from the bottom and place the nut on the top to make sure you have enough room to tighten them down.



Make sure to position the top panel so that the cutout is on top of the bolt as in the picture below. That is where the factory hard top bolt will be inserted to install your Side MOLLE Panels.



Step 3 - Install your side MOLLE Panels

You will now remove the factory Hard Top bolts and install the Side MOLLE panels using the same factory bolts that you removed.

Step 4 - Show Off Your Handy Work (Every Last Step Should be This)

Thank you again for purchasing from AAL. We greatly appreciate your support.

Please let us know what you think about the product and installation process. Also, if you have any feedback for us on our product, instructions or anything else please let us know at sales@americanadventurelab.com as we are striving to be better in every aspect!

If you are so inclined, please share your installation photos with us online:

- Facebook - <https://www.facebook.com/AmericanAdventureLab>
- Instagram - <https://instagram.com/americanadventurelab>

