



Instructions

JEEP JL/JT FRONT MOLLE DOOR PANELS

Thank you for purchasing your Jeep JL/JT Front MOLLE Door Panels from AAL! We greatly appreciate your trust in our company. We take that purchase and your commitment to us very seriously. If you have any questions along the way, please don't hesitate to give us a call at 385.202.4188.

****Please read all instructions carefully****

Tools Required:

- Phillips head screwdriver

What's included:

Parts

- Front Main Panel (2):

Hardware

- 8 x 5/8" Black Zinc Pan Head Screws 5



Install

To install, simply align the panel with the outer surface and screw into the plastic using (5) of the supplied pan head screws on each side with a screwdriver. The installation should be very easy and once complete should appear as it does below. The installation is identical on both sides.



Share Your Photos!

We take great pride in building our products and we hope that pride extends to you after installing your Jeep JL/JT Front MOLLE Door Panels. If you are able to share your photos online (Facebook and Instagram), please tag **@AmericanAdventureLab**. We would love to see how it turned out and give you some reciprocal attention in return!

Congrats! You're all done!

Thank you!

At American Adventure Lab, we strive to improve anywhere we can. If you experience any issues with this product or have any suggestions, please let us know.

If you have any questions or concerns, please don't hesitate to reach out to us at 385.202.4188 or via email at Support@erp.adventurelab.com.

